
Oxygen Cylinders and Associated Accessories Common Problems and Troubleshooting Guide



Oxygen is not flowing



The cylinder is empty

Replace the cylinder



Flowmeter knob or cylinder valve is closed

· Open the cylinder valves and regulator knob; check whether the pressure gauge & flow-meter registers readings



The regulator is faulty

· Close all the valves and replace the regulator

Leakage from the cylinder or the flowmeter



Cylinder is not properly connected to pressure regulator

Tighten all the fittings



Faulty or missing washer between the regulator and the cylinder

Replace the washer



The flowmeter seal is damaged or is loose.

• Replace the sealing washer and realign the flowmeter



Faulty cylinder

Label the cylinder as faulty and take appropriate action

The flowmeter ball is not moving, yet the oxygen is flowing



Faulty flowmeter

- · Close all the valves, disconnect the flowmeter and clean the insides of it. Reconnect the flowmeter and the valves, and test it
- · If problem persists, replace the flowmeter

Leakage cannot be located

Leakage is too small to be heard



- Apply soap/detergent water solution to joints.
- · Bubbles will show at leak point, Clean/replace the washer and tighten those joints

Pressure gauge does not show pressure, yet the oxygen is flowing



Faulty pressure gauge

Replace the pressure gauge



Faulty diaphragm of regulator

Replace regulator diaphragm

Refer to user and service manuals for more guidance; repair & maintenance to be conducted by trained and authorized technician ONLY

